

		Dry Methods				Wet Methods (tiles must be cleaned using dry methods before wet cleaning)									
		A1: Soft brush A2: Clean, dry, soft, white cloth A3: Vacuum system (with brush)		A4: Focus compressed air	H: Pencil erasers to remove fingerprints or pencil marks	B1: Moist cloth with no detergent C1: A moist cloth with mild detergent diluted in warm water		B2: Damp sponge with no detergent C2: Damp sponge with mild detergent diluted in warm water		D: Damp rough texture sponge; (using medium pressure)		F: High pressure water cleaning		G: Resistant to popular disinfectants (due to large number of types of disinfectants, always test a small area first)	
Mineral Solutions	ULTIMA ⁺ , ULTIMA ⁺ dB, ULTIMA ⁺ OP	✓	Daily		✓	✓	Weekly	✓	Weekly						
	OPTIMA	A1 & A3 Only	Daily		✓			B2 Only	Weekly						
	PERLA, PERLA dB, PERLA OP 0.95, PERLA OP 1.00, PERLA OP dB	✓	Daily			✓	Monthly	✓	Weekly						
	NEEVA COLORTONE NEEVA	✓	Daily		✓										
	Serene hA	✓	Daily		✓	✓	Monthly	✓	Weekly						
	ARUBA, ARUBA dB, ARUBA MAX COLORTONE Dune eVo	✓	Daily					✓	Weekly						
	PLAIN	✓	Daily		✓										
	FISSION FT	✓	Daily		✓										
Specific Solutions	BIOGUARD ACOUSTIC	✓	Daily		✓	✓	Daily	✓	Daily	✓	Weekly			✓	Daily
	BIOGUARD PLAIN	✓	Daily		✓	✓	Monthly	✓	Weekly					✓	Weekly
	CLEANROOM FL	✓	Daily		✓	✓	Weekly	✓	Weekly					✓	Weekly
	HYGIENE	✓	Daily		✓	✓	Weekly	✓	Weekly			✓ ⁽¹⁾	Twice Yearly		
	HYDROBOARD	✓	Daily		✓										
	CERAMAGUARD	✓	Daily		✓	✓	Weekly	✓	Daily						
	AQUABLOC	✓	Daily		✓	✓	Weekly	✓	Daily						
	ARUBA hH	✓	Daily					✓	Weekly						

⁽¹⁾Special instructions are available - Please consult us.



Wipeable with a dry cloth / soft brush (A1 - A2 - A3)



Can be cleaned using focus compressed air (A4)



Wipeable with a moist cloth (B1 - C1)



Washable with a sponge dampened in water containing mild soap or diluted detergent (B2 - C2)



Scrubable with water containing mild soap or diluted detergent (D)



Can be cleaned using a high pressure water spray (F)



Can be cleaned with disinfectants commonly used in healthcare premises (G)

[zentia.com](https://www.zentia.com)

GUD 137.2.07.23